



INSTALLATION INSTRUCTIONS FOR PART 95-6517HG

APPLICATIONS

Dodge Dart (base model) 2013-up 95-6517HG


KIT FEATURES

- Double DIN radio provision
- *Painted high gloss black*



KIT COMPONENTS

- A) Radio Trim Panel • B) Radio Brackets



WIRING & ANTENNA CONNECTIONS (sold separately)

AXXESS Interface: • AXVI-6523 Antenna Adapter: • 40-EU55

TOOLS REQUIRED

- Panel removal tool • Phillips screwdriver • Socket wrench • Cutting tool/air saw/Dremel

Table of Contents

Dash Disassembly

– Dodge Dart 2013-up 2-3

Kit Preparation 3

Kit Assembly

– Double DIN radio provision 4


CAUTION: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

NOTE: Refer to the instructions included with the aftermarket radio.


NOTE: This kit will require modifications to the factory bezel. A new bezel will be required to return to factory.

Dash Disassembly


1. Remove (1) plastic push-pin fastener from the right edge facing up on the panel above the radio and instrument cluster. (Figure A)
2. Unclip and remove the entire panel. (Figure A)
3. Unclip and remove the end panel on the driver's side of the dash. (Figure B)
4. Remove (1) Phillips screw on the edge of the knee bolster panel then unclip the panel and let it hang. **Note: You do not have to fully remove this panel.** (Figure C)



(Figure A)




(Figure B)




(Figure C)

5. Remove the screws securing the steering column gap cover into place, unsnap the top of the column trim and pull it back over the wheel far enough to remove the instrument/radio panel. (Figure D)



(Figure D)


6. To remove the instrument/ radio panel, remove eight screws across the top and one from the bottom left side. (Figure E, F)



(Figure E)

7. Remove the radio mounting screws and remove the factory radio.

Continued on next page




(Figure F)

Dash Disassembly


Sub dash modifications

1. Remove the (3) screws inside the cavity from behind the factory radio (these will not be used again). (Figure A)
2. Cut and remove the plastic from the factory radio cavity without cutting the areas supporting the factory radio mounting holes. (Shaded area in Figure A)
3. Using a pry tool, bend the metal bracket holding the factory radios rear support to the dash frame. Bend back and forth until the assembly breaks free for removal. (Figure B, C)


Continue to kit assembly



(Figure A)



(Figure B)




(Figure C)

Kit Preparation


Dash panel modifications

1. Cut 1/8 inch from each side of the radio opening of the factory radio panel to allow clearance for the aftermarket radio. (Figure A)
2. Snap the radio trim panel into the factory panel prior to putting it all back together. (Figure B)

Continue to kit assembly on back



(Figure A)



(Figure B)




INSTALLATION INSTRUCTIONS FOR PART 95-6517HG



Kit Assembly

Double DIN radio provision

1. Attach the brackets to the aftermarket radio with the screws supplied with the radio. (Figure A)
2. Locate the factory wiring harness and antenna plug in the dash. Metra recommends using the proper mating adapters from Metra and/or AXXESS.
3. Secure the radio/ bracket assembly to the dash.
4. Reassemble dash in reverse order of disassembly. Snap the radio trim panel over the instrument panel bezel prior to installation.



(Figure A)

REV 12/9/2013 INST95-6517HG



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians